

# Operating Instructions

## Kettle

- To fill: cordless – remove kettle from base; non cordless – remove cable from kettle
- Lift lid and hold kettle under a running COLD tap
- Fill to required amount – indicated on measurement guide on the side of the kettle
- Replace kettle to either base or cable
- Press lever switch to turn on and light will indicate operation
- When lights turns off the water is boiled
- To cancel boiling: press lever back or turn off at the mains plug
- Kettle will automatically turn off when boiling is finished



### Safety:

- Always fill enough water to cover the elements at the bottom of the kettle
- Never fill kettle over MAX indicator
- DO NOT open the lid when water is heating
- ONLY use the kettle to boil water – no other liquids or food should be used in any kettle

**If you are still unclear on the use of any appliance please speak to a member of staff.**

**If any appliance does not work – NEVER try to fix it yourself, always report it to reception.**

**And remember NEVER turn on an appliance and leave it unattended.**